

CLEANING AND STERILISING

To ensure that your baby stays well, it is vital that you keep all parts of the pump that come into contact with your milk clean.











HANDY TIP!
If you are a busy mum
who exclusively
pumps, because
breast milk is
antibacterial, you can
put your parts in a
clean bag into the
fridge after each pump
and sterilise at the end
of the day.

- Sterilise all parts (except main body / motor) daily.
- If you submerge the air tube in water, make sure you hang it up so that all drips have drained out and the tube is completely dry again.
- In between sterilising, wash parts that come into contact with milk in warm soapy water after each use.

